



AUTO ACE

Product/Technical Data Sheet (TDS)

Fibreglass Repair Kit

PRODUCT DESCRIPTION:

Omega Fibreglass Repair Kit contains everything you need to repair holes and cracks in most surfaces including fibreglass, steel, automotive panels, boats, wood, masonry, and other rigid materials. Contains 250ml Polyester Resin, 10ml Catalyst, 1m 300g Mat, Wooden Mixing Stick, and Brush.

DIRECTIONS FOR USE: SURFACE PREPARATION:

Use coarse to medium abrasive papers to prepare surface, then use Omega Acetone to thoroughly clean the repair area.

APPLICATION:

Measure out the desired quantity of resin and pour into a mixing container. For every 100ml of resin, add 1 to 2ml of Omega Catalyst and mix thoroughly. Working time (pot life) at room temperature is approximately 25 minutes. Position the Fibreglass Matting and apply the resin/hardener mix with a clean dry brush ensuring the matting is thoroughly saturated. For a higher build add more matting and resin/hardener mix as necessary. Avoid air bubbles. Any imperfections may be filled with Omega Body Filler and sanded again prior to finishing.

DRYING TIME: Hard at 2 hours.

CLEAN UP: Use Omega Acetone

STORAGE: Store upright in a cool, dry, well ventilated area away from heat, ignition sources and direct sunlight.

RISK: Harmful by inhalation. Irritating to eyes and skin.



AUTO ACE

SAFETY DIRECTIONS: Avoid contact with the skin and eyes and avoid breathing the vapour. Keep away from sources of ignition – **NO SMOKING**. Use in a well-ventilated area. Do not empty into drains. Store in a cool dry place. Always replace the lid securely after use.

Standard packages and Product Codes

250ML Kit – AA-FGR250ML